

## **S9203 | Perimeter / Rail Marking Installation**

For use as luminous egress path markers on walls, floors, and to mark handrails. It can also be used as the glow strip in nosing models STNC, STNP, STNR, and STNS. Adheres to smooth or lightly textured walls, smoother concrete floors, steel, aluminum, wood, and glass. Can also be used around the door frame to mark final exit.

**For compliant placement of perimeter, railing or nosings, consult your applicable local or national codes (2009, 2012 IBC section 1024 + 2015 IBC section 1025).**

### **Installation Steps:**

1. Thoroughly clean the surface area where the markings will be installed with isopropyl alcohol and a clean dry cloth to remove any loose particles, grease or dirt. Surface must be dry and dust free.
2. Cut to length with scissors.
3. Peel the backing from the marking material as it is applied and without touching the adhesive.
4. Place the markings as required, working from one end to the other applying firm pressure to affix to the surface.

**Maintain** by cleaning as needed with a cloth and/ or mild non-abrasive cleaner if needed.

**Photo-Glo Charge Instruction:**

Minimum of 1-foot candle (11 Lux) of fluorescent, incandescent or LED (light emitting diode) for 60 minutes is required to charge Photo-Glo.

Control of lighting restricted to authorized personnel. Reliable external illumination is always required during occupancy.

Do not use Photo-Glo where ambient illumination level is less than 1-foot candle (11 Lux).

If you have further questions, please contact us:

Call: 1-855-723-6673    Email: [sales@safetnose.com](mailto:sales@safetnose.com)